



Stand: 07.05.2026

Quick start guide for CLEVERTOUCH-Displays



1. Power On

Briefly press the power button located at the bottom right of the display. The LED will change from red to white.

Please wait about 30 seconds until the display has fully started up and shows the home screen.

Once you connect your laptop via USB-C (the cable is located on the right side of the display), the screen will automatically switch to your device.

The cable transmits both video and audio and provides up to 100 W of charging power.

2. Menu

You can open the menu using the pen icon, which is always visible on the screen. From there, you can select the input source and adjust additional settings.

3. Whiteboard Software - LYNX

LYNX is a whiteboard application for digital notes.

Please make sure to save your work on a USB drive, as the device's internal storage is publicly accessible.

4. File Explorer

Use the file explorer to access files stored on the device itself or on a connected USB drive.

5. Power Off

Once you unplug the USB-C cable, the display will automatically turn off after a short time.



Notes

- **Electric height adjustment:**

Do not place any objects underneath the display and keep clear of the lifting area!

- **Mobile displays:**

Please move the display cart with two people only and do not place it in emergency exit routes!



Support

- If you have any questions or issues, please contact the RRZ ServiceLine:
rrz-serviceline@uni-hamburg.de